California Dept of Transportation

MPQP

AC, PCC, Rubber & Other Batch Operations

Report Number 12-16 | calib date 4/23/2012 | district 01 | 109 by L Lee | plant controller Seltek

plant type HMA Batch | plant owner Mercer Fraser | plant location Fortuna Plant "A"

scale acceptable to 6,000 Lbs. | useable scale capacity 10000 | largest noted error, for this scale 1Grad

scale number 1 | material type asphalt | graduation size 1.0

step number	applied test weight	applied build-up weight	total applied weight	adjustment from last step	adjusted total weight	indicated weight	actual error	error in grads	USEABILITY	remarks
1	50	0	50	always zero for 1st step	50	50	0.0	0.0	Acceptable	
2	100	0	100	0	100	100	0.0	0.0	Acceptable	
3	150	0	150	0	150	150	0.0	0.0	Acceptable	
4	200	0	200	0	200	200	0.0	0.0	Acceptable	
5	250	0	250	0	250	249	-1.0	-1.0	Acceptable	
6	300	0	300	0	300	299	-1.0	-1.0	Acceptable	
7	350	0	350	0	350	349	-1.0	-1.0	Acceptable	
8	400	0	400	0	400	399	-1.0	-1.0	Acceptable	

scale acceptable to 400 Lbs | useable scale capacity 500 | largest noted error, for this scale 1 Grad

scale number 2 | material type cement | graduation size 10

step number	applied test weight	applied build-up weight	total applied weight	adjustment from last step	adjusted total weight	indicated weight	actual error	error in grads	USEABILITY	remarks
1	1000	0	1000	always zero for 1st step	1000	1000	0	0	Acceptable	
2	2000	0	2000	0	2000	2000	0	0	Acceptable	
3	3000	0	3000	0	3000	3000	0	0	Acceptable	
4	4000	0	4000	0	4000	4000	0	0	Acceptable	
5	5000	0	5000	0	5000	5000	0	0	Acceptable	
6	5990	0	5990	0	5990	5990	0	0	Acceptable	

scale acceptable to | useable scale capacity | largest noted error, for this scale

scale number | material type | graduation size

step number	applied test weight	applied build-up weight	total applied weight	adjustment from last step	adjusted total weight	indicated weight	actual error	error in grads	USEABILITY	remarks
				always zero for 1st step						

scale acceptable to | useable scale capacity | largest noted error, for this scale

scale number | material type | graduation size

step number	applied test weight	applied build-up weight	total applied weight	adjustment from last step	adjusted total weight	indicated weight	actual error	error in grads	USEABILITY	remarks
				always zero for 1st step						

Test Notes

PLANT CERTIFIED FOR STATE USE
INTERLOCKS O.K.
PRINTER O.K.
CONTROLLER SELTEC 920i